

吊下げ

店頭での吊下げ形態

- ①一般紙器
- ②レンズ箱














吊下げ部

- ①ヘッダー
- ②吊下げ片 (切起こし)
- ③吊下げ片 (箱内収納)

付加機能


- ・ヘッダー折曲げ
- ・棚置用自立底面脚部

ヘッダー式 一般形態




< 20年以上経過 > 一般紙器


13




17




21




25




14



18




22




26


15



19




23




27


16



20



24



28