

# 再封緘 (パネル)














再封緘用にパネルを追加した形態

形態種別

- ①糊代利用
- ②側面追加
- ③天面追加
- ④その他


フリップトップは別途掲載

手詰用フリップトップ




<20年以上経過> 一般紙器

13




17



21

25

14




18

22

26

15




19

23

27

16



20

24

28